


# XTRFY M42 MANUAL



## CPI

● 400

● 800

● 1200


● 1600

● 3200

● 4000



● 7200


● 16000



**POLLING RATE**

← 125 Hz 500 Hz 1000 Hz →







+




BRIGHTNESS



+





+

