


IRONCLAW RGB

FPS/MOBA GAMING MOUSE

GETTING TO KNOW YOUR MOUSE



- A — LEFT CLICK BUTTON
- B — RIGHT CLICK BUTTON
- C — MIDDLE CLICK BUTTON
- D — PROFILE CYCLE BUTTON
- E — DPI CYCLE BUTTON
- F — FORWARD BUTTON
- G — BACKWARD BUTTON
- H — MULTI-PURPOSE LED INDICATOR
- I — PTFE GLIDE PADS
- J — OPTICAL GAMING SENSOR
- K — USB CONNECTION CABLE

- G — BACKWARD BUTTON
- H — MULTI-PURPOSE LED INDICATOR
- I — PTFE GLIDE PADS
- J — OPTICAL GAMING SENSOR
- K — USB CONNECTION CABLE

SETTING UP YOUR MOUSE

- > Turn on your computer.
- > Connect the mouse to available USB 2.0 or USB 3.0 port on your computer.
- > Download the iCUE software from www.corsair.com/downloads.
- > Run the installer program.
- > Follow instructions for installation.

MULTI-PURPOSE LED INDICATOR

Various aspects of mouse operation are communicated through multi-purpose LED indicator located on the left side of the mouse.

ONBOARD PROFILE STATUS	MULTI-PURPOSE LED INDICATOR		
	LED #1	LED #2	LED #3
PROFILE #1	RED	OFF	OFF
PROFILE #2	OFF	GREEN	OFF
PROFILE #3	OFF	OFF	BLUE
DPI STAGE STATUS			
STAGE #1	CYAN	OFF	OFF
STAGE #2	CYAN	CYAN	OFF
STAGE #3	CYAN	CYAN	CYAN

For use only with NRTL listed end product and Mouse Rating: 5V $\overline{\text{---}}$ 200mA


CAUTION!
 The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

FC WARNING: Changes or modifications not expressly approved by CORSAIR MEMORY, Inc could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- > Reorient or relocate the receiving antenna.
 - > Increase the separation between the equipment and receiver.
 - > Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - > Consult the dealer or an experienced radio/TV technician for help.
- This device must not be co-located or operating in conjunction with any other antenna or transmitter. Operation is subject to the following two conditions:
 (1) this device may not cause harmful interference, and
 (2) this device must accept any interference received, including interference that may cause undesired operation.

PRÉSENTATION DE LA SOURIS



- A — BOUTON CLIC GAUCHE
- B — BOUTON CLIC DROIT
- C — BOUTON CLIC DU MILIEU
- D — BOUTON DÉFILEMENT DE PROFILS
- E — BOUTON DÉFILEMENT DE PPP
- F — BOUTON SUIVANT
- G — BOUTON PRÉCÉDENT
- H — VOYANT À DEL MULTIFONCTION
- I — PATINS EN PTFE
- J — CAPTEUR DE JEU OPTIQUE
- K — CÂBLE DE CONNEXION USB

CONFIGURATION DE LA SOURIS

- > Allumez votre ordinateur.
- > Branchez la souris sur un port USB 2.0 ou USB 3.0 disponible sur votre ordinateur.
- > Téléchargez le logiciel iCUE sur www.corsair.com/downloads.
- > Exécutez le programme d'installation.
- > Suivez les instructions d'installation.

VOYANT À DEL MULTIFONCTION

Le voyant à DEL multifonction permet de signaler les différents états de la souris. Il est situé sur le côté gauche de la souris.

STATUT DE PROFIL INTÉGRÉ	VOYANT À DEL MULTIFONCTION		
	LED 1	LED 2	LED 3
PROFIL 1	ROUGE	ÉTEINT	ÉTEINT
PROFIL 2	ÉTEINT	VERT	ÉTEINT
PROFIL 3	ÉTEINT	ÉTEINT	BLEU
STATUT NIVEAU PPP			
NIVEAU 1	CYAN	ÉTEINT	ÉTEINT
NIVEAU 2	CYAN	CYAN	ÉTEINT
NIVEAU 3	CYAN	CYAN	CYAN

